

# EHD Components 2005 (Pty) Ltd

**E-mail:**

JHB: ehd@ehd.co.za

CPT: ehdcapetown@ehd.co.za

DBN: ehd.dbn@ehd.co.za

BLOEM: ehdbloem@ehd.co.za

**Contact Number:**

JHB: +27 (0)11 870 5000

CPT: +27 (0)21 510 0567

DBN: +27 (0)31 700 1160

BLOEM: +27 (0)51 430 5404

Automatic mains failure panel

## Automatic mains failure panel

Generator controller monitor water temperature and cut out on engine temperature

Generator controller monitor oil pressure and cut off on low oil pressure

Controller monitor over generator voltage on all three phase

Controller monitor over load per phase and cut generator set

Controller monitor unbalanced phases

Controller can be configured for 3 phase or single phase

Controller can be set to do an automatic change over

## Disclaimer

Manufacturer's names, numbers, symbols, photos and descriptions are used for reference purposes only and it is not implied that the parts referred to are the products of those manufacturers

**Source: [www.ehd.co.za](http://www.ehd.co.za)**