

EHD Components 2005 (Pty) Ltd

E-mail:

JHB: ehd@ehd.co.za
CPT: ehdcapetown@ehd.co.za
DBN: ehd.dbn@ehd.co.za
BLOEM: ehdbloem@ehd.co.za

Contact Number:

JHB: +27 (0)11 870 5000
CPT: +27 (0)21 510 0567
DBN: +27 (0)31 700 1160
BLOEM: +27 (0)51 430 5404

Automatic mains failure panel

Automatic mains failure panel

Generator controller monitor water temperature and cut out on engine temperature
Generator controller monitor oil pressure and cut off on low oil pressure
Controller monitor over generator voltage on all three phase
Controller monitor over load per phase and cut generator set
Controller monitor unbalanced phases
Controller can be configured for 3 phase or single phase
Controller can be set to do an automatic change over

Disclaimer

Manufacturer's names, numbers, symbols, photos and descriptions are used for reference purposes only and it is not implied that the parts referred to are the products of those manufacturers

Source: www.ehd.co.za